



Eliminating single-use plastics globally.

Starting Up Machines

Standard Operating Procedure

Start-of-shift procedure for the Rhima RP3 Wash and Sanitise machines.

Prepared for	TUW partner dairies
Prepared by	The Udder Way M.D. Pty Ltd
Date	22 May 2026

Document control

Document ref	TUW-SOP-STARTUP-01
Revision	1.1
Issued	22 May 2026
Original release	17 May 2024
Next review	22 May 2027
Prepared by	Kurtis Tupangaia — Key Account Manager
Approved by	Ed Crick — Managing Director & Founder

Procedure

Step	Instruction
1	Ensure water running to the machines is switched on, and power is switched on.
2	Check chemical levels for each machine and ensure the pickup spigots are completely submerged.
3	Hold down the power button on both machines until the screen says “ Filling ”.
4	Once the tank is full, the machine will begin “ Heating ”. This whole process will take approximately 20 minutes .
5	The screen will change to the Rhima symbol when the machine is fully heated and ready to use.