



Eliminating single-use plastics globally.

Cleaning & Closing Machines

Standard Operating Procedure

End-of-shift cleaning and shutdown procedure for the Rhima RP3 Wash and Sanitise machines.

Prepared for	TUW partner dairies
Prepared by	The Udder Way M.D. Pty Ltd
Date	22 May 2026

Document control

Document ref	TUW-SOP-CLEAN-01
Revision	1.1
Issued	22 May 2026
Original release	17 May 2024
Next review	22 May 2027
Prepared by	Kurtis Tupangaia — Key Account Manager
Approved by	Ed Crick — Managing Director & Founder

Procedure

Step	Instruction
1	Remove 2x stainless steel filters from each machine.
2	Hold down the Power button on each machine until the machine switches off.
3	Hold down the Drain button (4th button on the bottom) on each machine until the screen says “ Draining ”. This will take approximately 10 minutes .
4	Scrub filters in hot, soapy water to remove any scum or particulate.
5	Once the drain cycle is complete, begin the self-cleaning cycle by pressing Start . This will take approximately 2 minutes .
6	Once the self-cleaning cycle is complete, place filters back inside the machine.