



Eliminating single-use plastics globally.

# Preventative Maintenance

## Standard Operating Procedure

Weekly and quarterly preventative-maintenance procedure for the Rhima RP3 Wash and Sanitise machines.

---

Prepared for	TUW partner dairies
Prepared by	The Udder Way M.D. Pty Ltd
Date	22 May 2026

# Document control

Document ref	TUW-SOP-MAINT-01
Revision	1.1
Issued	22 May 2026
Original release	17 May 2024
Next review	22 May 2027
Prepared by	Kurtis Tupangaia — Key Account Manager
Approved by	Ed Crick — Managing Director & Founder

## Weekly

Once per week, scrub the inside of the wash tanks on each machine.

## Every 3 months — descale

Step	Instruction
1	Remove chemical pickup lines from chemical drums.
2	Fill washer and manually dose descaler into wash tanks.
3	Drain tanks and run self-cleaning cycle.
4	Refill with just water.
5	Run wash cycle once.
6	Drain tanks and run self-cleaning cycle.
7	Reconnect chemical pickup lines to chemical drums.